



SPECIFICATIONS	
MODEL	MAC 60R
AIR FLOW	2.1 CFM
NORMAL PRESSURE	2.2 PSI
POWER	120V/1.3A/60Hz
OUTLET CONNECTION	3/4 INCH
WEIGHT	10 LBS
POWER CONSUMPTION	45 W
POWER CABLE	6 FEET

- Installation / Operation & Maintenance Notes:
- Install blower on concrete base. Ensure adequate ventilation and protect against sunlight.
 - Maintenance requires a trained technician.
 - For maximum efficiency, inspect and clean internal air filter once every 3 months
 - Replace diaphragm / valve assembly once every 12 months (Note: A damaged diaphragm will trigger the Automatic-Stop function).

MAGBLOWERS



BLOWER
MAC 60R

DATE: 06/17/2014 SCALE: 3" = 1"